

Table 298 - Unit Hardware and Kits (continued)

Description			Catalog Number	Price	Delivery Program	
External Auxiliary Contact	One (1) Normally Open	Must be used with external auxiliary adapter kit	Unit Series Q or later	2100H-N19	\$50	SC
	One (1) Normally Closed			2100H-N20		
FOR BOLTED PRESSURE SWITCHES: For 2192F and 2192M 600A, 800A and 1200A units.	Mounts one (1) form C auxiliary contact on the operating mechanism, external to the bolted pressure switch	Unit Series Q and later	2100H-N26A	120		
	Mounts two (2) form C auxiliary contacts on the operating mechanism, external to the bolted pressure switch		2100H-N26B	185		

(1) Plug-in units have provision for a maximum of four (4) pull-apart terminal blocks (any combination of 3-pole or 5-pole blocks). Not available on 0.5 space factor units.

(2) 1.5 space factor Bulletin 2193F with 225 A frame breakers, use kit 2100H-NXT05B2.

(3) Kit permits mounting of two (2) Bulletin 595-A (normally open) or 595-B (normally closed) auxiliary contacts only. Not compatible with Bulletin 1495-NB or 1495-NP auxiliary contact kits.

Table 299 - Unit Hardware and Kits (continued)

Description			Catalog Number	Price	Delivery Program	
External Auxiliary Contact Kits	FOR CIRCUIT BREAKERS: For 0.5 space factor units. Auxiliaries are actuated by the unit operating handle only and will not reflect a circuit breaker trip	Mounts one (1) form C auxiliary contact on the operating mechanism, external to the breaker. Allen-Bradley I-Frame or JD-Frame or Cutler-Hammer 150A HMCP, FDB, FD, HFD, FDB-LFD, FDC and 225A JD, HJD and JDC.	Unit Series P and later	2100H-N18A	\$110	SC
		Mounts two (2) form C auxiliary contacts on the operating mechanism, external to the breaker. Allen-Bradley I-Frame or JD-Frame or Cutler-Hammer 150A HMCP, FDB, FD, HFD, FDB-LFD, FDC and 225A JD, HJD and JDC.		2100H-N18B	155	
	FOR CIRCUIT BREAKERS: For dual 2103, 2113 and 2193F units	Mounts one (1) form C auxiliary contact on the operating mechanism, external to the breaker. Allen-Bradley I-Frame or Cutler-Hammer FDB, FD, HFD, FDB-LFD and FDC.	Unit Series Q and later	2100H-N25A	110	
		Mounts two (2) form C auxiliary contacts on the operating mechanism, external to the breaker. Allen-Bradley I-Frame or Cutler-Hammer FDB, FD, HFD, FDB-LFD and FDC.		2100H-N25B	155	